



This Interface can support the control of radio brand and can be installed in the Asian and European car brand listed in below table. Selection of the radio or car brand can be done easily by using any Sony TV remote control

How to install and select radio and car brand accordingly

1. Connect power cord into the key switch ACC and ground to order
2. Point the Sony TV remote Control in the direction of Steering Remote Interface installed
3. Press the selected radio and car brand number corresponding to below table list

Example To use PIONEER radio, press the number “0 0 0 “. And if HONDA is the car brand, press the number “2 0 0 “. After each successful selection of radio or car brand, LED will blink 3 times Continuously after last digit is pressed.

Normally the default system is set to PIONEER car radio as a vehicle is not selected , so if you want To use the car with PIONEER radio , it is selected by default, you do not need to select radio again
*** Below are Code table for radio and car.

Car audio	Number	Controls
Made for Pioneer	000	W/R NEW VERSION/ WITH BLUE TOOTH FUNCTION
Made for Pioneer	001	W/R OLD VERSION/ WITH BLUE TOOTH FUNCTION
Made for Pioneer	002	INFRARED/ WITH BLUE TOOTH FUNCTION
Made for KENWOOD	005	WIRE / INFRARED WITH BLUE TOOTH FUNCTION
Made for ALPINE	010	PLUG / INFRARED WITH BLUE TOOTH FUNCTION
Made for JVC	015 STANDARD	WIRE/OE/INFRARED
Made for JVC	016 Command 48Bit	INFRARED/ WITH BLUE TOOTH FUNCTION
Made for Clarion	025 STANDARD	OEM / INFRARED
Made for Clarion	026 2 DIN VX, VZ	OEM / INFRARED
Made for Sony Mobile	030 STANDARD	PLUG / INFRARED
Made for Panasonic	035 2 DIN	WIRE / INFRARED
Made for KAMAZ	050 HD 3D	WIRE / INFRARED WITH BLUE TOOTH FUNCTION
Made for KAMAZ	051 MOVE	WIRE / INFRARED
Made for ZULEX	056 Y2010 UP	WIRE / INFRARED

Automobile	Number	Model Cars
CIVIC CRV	200	ALL NEW CIVIC, CRV 2012
CHEVROLET CRUZE	203	CRUZE , <i>Sonic</i>
VOLVO	206	s60, s80, v70 , xC70 , xC90
DODGE	209	JOURNEY
Jeep	209	GRAND CHEROKEE WRANGLER Y2011
MINI	212	e90, MINICOOPER S
BMW	213	e60
BMW	214	e65
CHRYSLER	215	300c
Audi	218	<i>TT</i>
Volkswagen	221	GOLF GTI, PASSAT, CARAVELLE
PORSCHE	224	CAYENNE S
FIAT	227	<i>500</i>
Mercedes-Benz	230 *	W211, W169, W203>Y2004 W639>Y2006, W164>Y2005
Mercedes-Benz	231	W204, W207, W212
Mercedes-Benz	232 *	W203<Y2004 , W209 , R171
Mercedes-Benz	233 *	W208 , W210 , W220
Mercedes-Benz	234 **	W211, W169, W203>Y2004 W639>Y2006, W164>Y2005
Mercedes-Benz	235 **	W203<Y2004 , W209 , R171
Mercedes-Benz	236 **	W220
PEUGEOT	228	RCZ , 408

* include with Source Mute
** include with Blue Tooth function



Be careful to choose the correct type of car , Do not try any other of vehicle Than the car you want to install

